



TYPICAL AIR TRACTOR SWATH WIDTHS (Feet)

Gallons per Acre						
Aircraft	1	2	3	5	8	10
AT402	69	69	66	63	60	57-60
AT502	72	70	70	66	63	60-63
AT602	78	75	75	72	66	66-70
AT802	90	85	82	76	75	72-78

Per Dr. Dennis Gardisser

TYPICAL AIR TRACTOR SWATH WIDTHS (Meter)

Liter per Hectare						
Aircraft	9	19	28	47	75	94
AT402	21	21	20	19	18	17-18
AT502	22	21	21	20	19	18-19
AT602	24	23	23	22	20	20-21
AT802	27	26	25	23	23	22-23

Per Dr. Dennis Gardisser

The above information is intended as a starting point reference. Information gathered by Dr. Dennis Gardisser over the years from pattern clinics. To know your optimum swath width for any aircraft, attend a pattern clinic. Let the experts help guide you to the settings that work for you!